

## Wall Tattoo Installation Instructions

To prepare your wall, wipe the area down with a **dry** cloth to be sure there is no dust. Do not use a wet cloth. Do not apply to freshly painted walls. Allow 30 days for freshly painted walls to dry.

### Step 1



### 1. Prep Your Wall Tattoo

Take your wall tattoo out of the shipping tube and lay face up on a flat, firm surface. Use the included squeegee in the middle of the tattoo and press toward the edge to squeeze the air bubbles out.

### Step 2



### 2. Pull Backing Paper Off 4-6 Inches

Place your tattoo on the wall to determine and mark your desired position with a pencil. Place the tattoo face down on a flat surface and pull the backing paper away 4-6 inches. Cut this backing paper away with a scissor.

*Tip: Use masking tape to hold the tattoo temporarily against the wall while you determine the ideal location.*

### Step 3



### 3. Place Tattoo on Wall

Use the exposed sticky area to position and hold your tattoo on the wall. Press this area down firmly with the included application squeegee.

*Tip: Squeegee from the center of the tattoo to the edge.*

### Step 4



### 4. Remove Backing Paper

With tattoo firmly attached to the wall, start removing the remaining white backing paper as you continue to apply the tattoo.

*Tip: A 2nd person can help remove the backing paper as the 1st person squeegees down the tattoo.*

### Step 5



### 5. Squeegee Side to Side

Use the squeegee to press the tattoo onto the wall in a side to side manner to prevent air bubbles. Begin in the middle and firmly press out to the edges.

### Step 6



### 6. Peel Masking Paper Off

Go over the tattoo with your squeegee firmly to ensure the tattoo has adhered. Pull up a corner of the masking paper and peel it slowly, straight down along the wall to reveal your tattoo.

*Tip: If a piece of your tattoo lifts off the wall as you remove the masking paper, stop and re-apply the lifted piece with the squeegee. Then continue to peel back the masking paper.*